


Light Power Meter Instruction Manual



- 1. Turn on the power switch.
- 2. Push color button several times for setting the target wavelength.

- **3.** Expose the sensor to the target light source. If you measure a light from optic fiber, the fiber end should touch the surface of the sensor at center, vertically.
- **4.** You should see the value of light power from the source on the LCD panel.

^{*} For reducing background of the environmental light, we recommend that the measuring should be done in the box-like cover for making a shade on the sensor.





Contact us: info@amuzainc.com (858) 225-6869 www.amuzainc.com